

First results from the E332 Experiment:
Near-Field-CTR based Self-Focusing
Effects and Target Damage Mechanism
with High Intensity Beams at FACET-II

20th Advanced Accelerator
Concepts Workshop

Doug Storey, FACET-II, SLAC National Accelerator Laboratory
On behalf of the E332 Collaboration

November 6-11, 2022



Facility for Advanced
Accelerator Experimental Tests

Collaboration list



I. Andriyash, S. Corde, M. Gilljohann, A. Knetsch, O. Kononenko,
Y. Mankovska, A. Matheron, P. San Miguel Claveria, V. Zakharova



C. Keitel, S. Montefiori, A. Sampath, M. Tamburini



X. Davoine, J. Faure, L. Gremillet, S. Passalidis



R. Ariniello, H. Ekerfelt, C. Emma, F. Fiuza, E. Gerstmayr, S. Gessner,
M. Hogan, A. Marinelli, J. Peterson, B. O'Shea, D. Storey, X. Xu, V. Yakimenko



C. Joshi, K. Marsh, W. Mori, N. Nambu, Z. Nie, Y. Wu, C. Zhang



J. Cary, C. Doss, K. Hunt-Stone, V. Lee, M. Litos




E. Adli




J. Yan, N. Vafaei-Najafabadi

Near Field Coherent Transition Radiation Self Focusing


Initial beam fields – electric and magnetic:



Fields at foil surface:






- A dense beam colliding with a conducting surface experiences strong CTR
 - E field at surface $\rightarrow 0$
 - B field at surface $\rightarrow \sim x2$
- CTR drives strong magnetic fields on the surface \rightarrow strong Lorentz force self focusing
- Beam size propagation after a single foil:
 - FACET-II bunch parameters
 - $\epsilon_n = 3 \mu\text{m-rad}$
 - $\sigma_r = 10 \mu\text{m}, \sigma_z = 0.5 \mu\text{m}$
 - $Q_b = 2 \text{ nC}$



3D PIC simulations performed by A. Sampath

Near Field CTR Self Focusing through multiple foils

- Effect is enhanced by passing the beam through multiple foils
- Beam can be focused to radial density of order 10^{29} m^{-3}
- CALDER simulations showing beam distribution and magnetic field intensity



Figures by X. Davoine
Sampath, A, PHYSICAL REVIEW LETTERS **126**, 064801 (2021)

Generation of extremely intense Gamma-rays

- Focusing is accompanied by the emission of a short, collimated pulse of gamma photons
- Photons are generated with strong conversion efficiency and exceeding solid density

- Beam distribution after 16 foils:



- $3.8 \times 10^{29} \text{ m}^{-3}$

- Gamma distribution:

- $2.8 \times 10^{29} \text{ m}^{-3}$

- 5 mrad aperture

- 4 fs FWHM



See talk by P. San Miguel on Tues. in WGs 2+7



Sampath, A, PHYSICAL REVIEW LETTERS **126**, 064801 (2021)

E332 experimental setup a FACET-II

- Uses FACET-II beams with ultra-high intensity
- Aluminum foils at FACET-II IP
 - Currently 0.1-2mm thickness, single foils
- Spectrometer beamline to diagnose electron and gamma beams

Electron Beam Parameter		Current FACET-II Parameters	Operational Ranges
Final energy	[GeV]	10	4 – 13.5
Charge per pulse	[nC]	1.6	0.7 – 5
$\gamma\epsilon_{x,y}$ at S19	[μm]	~ 20	3 – 6
Min spot size	[μm]	$\sim 30-40$	
Min bunch length	[μm]	~ 20	0.7 – 20
Max peak current	[kA]	--	10 - 200

Single foils at FACET-II IP:



- Reimaging electron spectrometer
- Gamma radiation diagnostics


FACET-II IP Area

Spectrometer Quads

Spectrometer Dipole


Diagnostics summary

- Observables:
 - Change to the vacuum propagation of e- beam
 - Increase in the beam divergence due to focusing, and change in focal plane of the beam
 - Energy spectrum after efficient energy loss to gamma beam
 - Gamma ray intensity and spectral measurements
- FACET IP diagnostics:
 - “Frontview” camera to image foil surface
- FACET-II spectrometer:
 - Reimaging triplet
 - Dipole bend with nominal 60mm dispersion
 - “Dump table” electron and gamma diagnostics





FACET-II Spectrometer diagnostics

- Electron beam diagnostics
 - **DTOTR** – high resolution profile monitor:
 - $\sim 4.5\mu\text{m}$ imaging resolution
 - $\sim\text{fs}$ longitudinal resolution w. XTCAV
 - **LFOV** and **CHER**– large field of view electron spectrometers
 - 0.4% energy resolution
- Photon diagnostics:
 - **Gamma1**: scintillator photon profile monitor
 - **Gamma2** and **3**: spectral info from $<100\text{keV}$ to 10's of MeV
 - Upcoming: Compton and Pair spectrometers \rightarrow 10 GeV spectrum




Gamma2 and 3 gamma screens:





Target damage mechanism

- Two modes of heating:
 1. Bulk heating from collisional dE/dx
 2. Ohmic heating from image currents on surface
- Beam fields drive strong image currents in the foil surface
 - Currents penetrate within a skin depth of the surface
 - Result in Ohmic/resistive losses and surface heating
 - Stupakov, G., SLAC-PUB-15729 (2013)
- For a typical FACET-II 2022 run:
 - Beam size: $\sigma_{x,y,z} \sim 20 \times 40 \times 20 \mu\text{m}^3$
 - Collisional heating: $\Delta T_{dE/dx} \cong 100^\circ\text{C}$
 - Ohmic heating: $\Delta T_{dE/dx} \cong 500^\circ\text{C}$ at surface




Diagnostics for target damage studies

- Camera to visualize damage in real time
- Gamma diagnostics to measure bremsstrahlung photon signal
- General radiation monitors





FrontView camera – 13-Aug-2022 01:57:33



Single and multi-shot damage

- Single shot damage – *top row*
 - Surface damage from single 1.6nC shot
 - Transverse size of 100-250 μm
- Multi-shot damages – *lower row*
 - 0.1mm Al melted through in 1000-2000 shots
 - ~50-100 nm of material removed/shot
 - Rate of etching through, and hole size depends on longitudinal compression
- Next steps
 - Parameter scans with reproducible parameters
 - Repeat with different materials
 - i.e. melting point, conductivity, etc





Initial search for NF-CTR focusing


- Target foil rastered at the beam rate to provide “fresh” surface for each shot
- Spectrometer set for large M_{12} to enhance the divergence signal
- Change in divergence above the multiple scattering not visible with present beam parameters

Analysis by A. Matheron, LOA

Beam size propagation - $\epsilon_n = 30 \mu\text{m}$







Divergence for different energy slices



Object plane scans

- Scan of spectrometer quads, with single shot per foil position
- Higher divergence with foil, but no sign of change in focal position




Analysis by A. Matheron, LOA


Next steps to demonstrate NF-CTR self focusing

- Focusing effect difficult to measure with present FACET-II beam parameters
 - Change to divergence is dominated by multiple scattering in foil
 - Change in waist position of cm's difficult to resolve, for now
- Repeat these scans with:
 - Smaller emittance and spot size as FACET-II commissioning progresses
 - Replace 100 μm foils with $\sim 1 \mu\text{m}$ foils
- Move on to multiple foils to enhance effect

Beam size propagation - $\epsilon_n = 30 \mu\text{m}$




Beam size propagation - $\epsilon_n = 3 \mu\text{m}$



Upcoming: Multi-foil experiments

- Enhanced NF-CTR with multiple foil interactions
- Multi-foil stack with fixed foil spacing being designed
 - Interleaved stainless “screen” and Al foil
 - 1mm hole spacing, ~300 positions

- Simulations:
 - 2 nC, 10 GeV
 - $\sigma_z = 5 \mu\text{m}$
 - $\sigma_r = 5 \mu\text{m}$



Credit – M. Gilljohan

Summary

- Near Field CTR can result in strong transverse fields at a foil surface boundary that can have a strong impact on the beam:
 - Strong self focusing to achieve electron beams of solid-density
 - Intense emission of gamma-ray photons
- E332 aims to study this effect using single and multi-foil experiments with the high intensity beams at FACET-II
- Commissioning and first studies have been performed over the summer-2022 run
- As the beam parameters continue to improve we expect to be able to resolve the NF-CTR effect on our diagnostics



Questions?

20th Advanced Accelerator Concepts Workshop

November 6-11, 2022

First results from the E332 Experiment: NF-CTR Self Focusing @ FACET-II

- Near Field Coherent Transition Radiation (NF-CTR) can result in strong transverse fields at a foil surface boundary that can have a strong impact on the beam:
 - Strong self focusing to achieve electron beams of solid-density
 - Drives the generation of an intense, collimated gamma beam
- E332 aims to demonstrate and probe these effects
- Progress and next steps:
 - Diagnostics and acquisition tools developed
 - Studies to understand target damage mechanism underway
 - NF-CTR self focusing not resolvable under current conditions
- Resolution of the NF-CTR effects are expected in upcoming run with smaller emittance beams and multi-foil targets

